

Preform Perpendicularity Tester



Preform Perpendicularity Tester is a consistent tool that helps the manufacturer in testing the perpendicularity of PET preforms. It is based on the principle to test the accuracy of the shape and size of preforms.

- Easy and accurate readout
- Comes with Zero Tolerance
- Adjustable measurement operations
- Repeatability in test measurements of preforms

With Preform Perpendicularity Tester, PET Preform Perpendicularity is checked as it is dependent upon the shape, size and quality of product. It has a basic turntable where the preform is placed and rotated with a probe checking the differential in movement.

Key Specifications:

Range	0 – 10 mm
Least count	0.001 mm
Display	LCD (Digital)
Preform Holder Diameter	As per requirement (Single holder part of supply)

Highlights:

Gauge	1
Dimensions	310 x 100 x 275 mm
Stand	Magnetic adjustable arm stand

**Various size preform holder diameter options available on requirement.

Comes with height adjusting knob to adjust the height of gauge. Highly accurate and reliable instrument to measure the Perpendicularity of Preforms.

Optional :

Preform holder different dia meter available on request.

Testronix Instruments

I-10A, DLF Industrial Area, Phase-1, Faridabad 121003, Haryana, India

P : 9313 140 140 E : info@testronixinstruments.com

www.testronixinstruments.com

