



**TESTRONIX<sup>®</sup>**  
INSTRUMENTS

I-10A, DLF Industrial Area, Phase-1, Faridabad 121003, Haryana, India

P : +91 9313140140 E : info@testronixinstruments.com W : www.testronixinstruments.com

## Notch Cutter

The notch cutter has immense importance for making a notch in the izod charpy samples. This is specimen preparation equipment that makes samples for izod dart impact tester to test the plastic sheets. This equipment assists in making a notch (upto 5mm)

The testronix notch cutter is durable and reliable instrument. It is a very easy to operate and convenient instrument. The instrument consist of a motorized mechanism which further makes the operation easy.



### Features

- Highly accurate Cutting for sample
- Strong gripping fixtures for Izod V-Notch sample preparation
- Cutting system motorised operation
- V- Notch measurement thought precession micrometer  
Top View Front View Side View Accessories
- Notch depth comparator feature
- Robust & high strength body

### Specifications

- Angle of Notch 45 degree
- Micrometer Range 0 - 25mm Micrometer
- Least Count 0.01mm
- Depth of Notch 2.5mm  $\pm$  0.05
- Power 220V Ac, 5 Amp., Single phase, 50 Hz
- Dimensions: 314 x 359 x 237 mm
- Mild steel structure

