



Preform Perpendicularity Tester



Preform Perpendicularity Tester is a consistent tool that helps the manufacturer in testing the perpendicularity of PET preforms. It is based on the principle to test the accuracy of the shape and size of preforms.

- Easy and accurate readout
- Comes with Zero Tolerance
- Adjustable measurement operations
- Repeatability in test measurements of preforms

With Preform Perpendicularity Tester, PET Preform Perpendicularity is checked as it is dependent upon the shape, size and quality of product. It has a basic turntable where the preform is placed and rotated with a probe checking the differential in movement.

Key Specifications:

Range	0 – 10 mm
Least count	0.001 mm
Display	LCD (Digital)
Preform Holder Diameter	As per requirement (Single holder part of supply)

** Various size preform holder diameter options available on requirement.

Highlights:

Gauge	1
Dimensions	310 x 100 x 275 mm
Stand	Magnetic adjustable arm stand

Comes with height adjusting knob to adjust the height of gauge. Highly accurate and reliable instrument to measure the Perpendicularity of Preforms.

Optional:

Preform holder different dia meter available on request.

