



**TESTRONIX**<sup>®</sup>  
INSTRUMENTS



## COBB SIZING TESTER

Cobb Tester helps in determining the amount of water absorbed by paper or board at a given point of time. The water absorptiveness also known as 'cobb value' of a substance is defined as the mass of H<sub>2</sub>O absorbed by 1 sq. meter sample of paper or corrugated box.

Testronix Cobb Tester assists in measuring the amount of liquid penetration into a sheet of paper or cardboard accurately.

Cobb Sizing Tester is designed as per industry standards IS **1060**, TAPPI-T441

### MODEL NO. TX-CT 100



**Fast Locking  
Mechanism**



**Corrosion  
Resistant  
Body**





**TESTRONIX<sup>®</sup>**  
INSTRUMENTS



## FEATURES

- Durable structure with corrosion resistant main body
- Light weight and resilient structure
- Rapid Locking Mechanism
- Single handed easy operation
- Highly accurate test results

## SPECIFICATION

- Sample Diameter 130 mm (approx)
- Depth of cylinder 60 mm
- Diameter of rubber pad 145 mm
- Water level indicator in cylinder 10 mm and 25 mm
- Weight of roller 10Kg (approximate)
- Stainless steel /mild steel body

*Thank you customers for choosing us as your partners in growth !*



\*All the above logos are the sole property of their respective owners and are used purely for depiction purposes only.

## OUR OTHER PRODUCTS :-

|                        |                          |                        |             |                    |         |
|------------------------|--------------------------|------------------------|-------------|--------------------|---------|
|                        |                          |                        |             |                    |         |
| Box Compression Tester | Bursting Strength Tester | Tensile Tester Digital | Drop Tester | Cobb Sizing Tester | GSM Kit |

