



TESTRONIX[®]
INSTRUMENTS



COBB SIZING TESTER

Cobb Tester helps in determining the amount of water absorbed by paper or board at a given point of time. The water absorptiveness also known as 'cobb value' of a substance is defined as the mass of H₂O absorbed by 1 sq. meter sample of paper or corrugated box.

Testronix Cobb Tester assists in measuring the amount of liquid penetration into a sheet of paper or cardboard accurately.

Cobb Sizing Tester is designed as per industry standards IS **1060**, TAPPI-T441

MODEL NO. TX-CT 100



**Fast Locking
Mechanism**



**Corrosion
Resistant
Body**





TESTRONIX[®]
INSTRUMENTS



FEATURES

- Durable structure with corrosion resistant main body
- Light weight and resilient structure
- Rapid Locking Mechanism
- Single handed easy operation
- Highly accurate test results

SPECIFICATION

- Sample Diameter 130 mm (approx)
- Depth of cylinder 60 mm
- Diameter of rubber pad 145 mm
- Water level indicator in cylinder 10 mm and 25 mm
- Weight of roller 10Kg (approximate)
- Stainless steel /mild steel body

Thank you customers for choosing us as your partners in growth !



*All the above logos are the sole property of their respective owners and are used purely for depiction purposes only.

OUR OTHER PRODUCTS :-

Box Compression Tester	Bursting Strength Tester	Tensile Tester Digital	Drop Tester	Cobb Sizing Tester	GSM Kit

