



TESTRONIX[®]
INSTRUMENTS



Preform Perpendicularity Tester

Preform Perpendicularity tester is an important instrument and has crucial application in the PET and preform industry. It is used to test the shape and size of the Preform.

The specimen is placed and rotated with a probe on a turntable. This calculates and checks the differential movement. The quality of the Bottle depends on the shape and size of the preform. Hence these specific Preformations play an important role in ascertaining the quality and durability of the PET bottle.

Our perpendicularity tester is a highly precise option for manufacturers to test and check their samples. It is a consistent tool and provides easy operation to the user.

MODEL NO. TX-PT 100



Digital Dial Gauge





TESTRONIX[®]
INSTRUMENTS



FEATURES

- Easy and accurate operations.
- Consist with Zero Tolerance.
- Adjustable measurement operations available
- Repeatability in test measurements of bottles/blow molded containers

SPECIFICATION

- Range 0– 10 mm
- Least count 0.001 mm
- Display LCD (Digital)
- Linearity Check ± 0.010 mm with slip gauge

Thank you customers for choosing us as your partners in growth !



*All the above logos are the sole property of their respective owners and are used purely for depiction purposes only.

OUR OTHER PRODUCTS :-

Vacuum Leak Tester Touch Screen	Torque Tester Touch Screen	Hot Water Bath	Bottle Burst Tester Digital	Polariscope	Flip Cap opening tester Touch Screen

