



## Tensile Strength Tester Digital

Tensile Strength Tester is one of the most used instruments in the packaging industry. The Tensile Strength Tester helps in calculating the tensile force which acts on the specimen. During the test the specimen is placed between the clamps. The clamps are then separated automatically. Due to the separation, force applied on the specimen leads to destruction. The Tensile Strength instrument hence records the peak value at which the destruction took place and displays it on the digital display. This instrument offers highly accurate values to the users. This makes the instrument user friendly and adaptable.

Various standards are adhered to which are as follows: **ASTM D412, ASTM D429-73, ASTM D624, ASTM D638-01, ASTM D76, IS 13360-5-7, IS-3400**

**MODEL NO. TX-TST**



**Micro Processor  
Base Digital Display**



**Safety Limit Switch**

## FEATURES

- Advanced load sensor sensing through advanced electronics.
- Highly sensitive load sensor
- Rugged and robust body
- Safety limit switches for over travel safety
- Highly accurate micro-controller based system controls
- Peak Hold facility available
- Precise elongation feature
- Powder coated corrosion resistant structure
- Ergonomically designed structure
- Single column rugged structure

Optional features available-

1. Computerised software
2. Customised pneumatic grips
3. Speed drive/ speed controller

## SPECIFICATION

- Accuracy –  $\pm 0.5\%$  of Load Cell Capacity
- Travel length of the grips – 25mm – 700mm.
- Motor – 1/5 HP, – 1440 rpm, 1 phase power supply.
- Grip to grip separation: Min 25mm and max 700mm
- Flexural
- Compression
- Plate Wedge Type
- Roller Type
- Vice grips

- Capacities available

Capacity	Least Count
5	1gm
10	1gm
20	2gm
50	5gm
100	10gm
250	10gm
500	100gm

*Thank you customers for choosing us as your partners in growth !*



\*All the above logos are the sole property of their respective owners and are used purely for depiction purposes only.

## OUR OTHER PRODUCTS :-

					
<b>Box Compression Tester</b>	<b>Bursting Strength Tester</b>	<b>Tensile Tester Digital</b>	<b>Drop Tester</b>	<b>Cobb Sizing Tester</b>	<b>GSM Kit</b>